



Digital-analogue gravity position indicators



ELESA Original design







technical informations

Case

Glass-fibre reinforced polyamide based (PA) technopolymer. Moulded-in spindle. Resistant to solvents, oils, greases and other chemical agents.

Bezel

Technopolymer. Moulded over the window.

Colour

Black, matte finish.

Window

Transparent polyamide based (PA-T) technopolymer (practically unbreakable). Resistant to solvents, oils, greases and other chemical agents (avoid contact with alcohol during cleaning operations).

Dial

Natural matte anodised aluminium. Clockwise or anti-clockwise graduation, black colour.

Reading

Five-digits roller counter (four black rolls and one red roll) and one red pointer which turns on the graduated dial. The digit of the red roll shows the decimal values, while the pointer shows the hundredth.

The display indicates the displacement of the mechanism controlled by the spindle from the start position (0). One complete turn of the machine spindle corresponds to a turn of the handwheel/knob and consequently to a turn of the red pointer. A turn of the red pointer corresponds to a determinate reading on the counter (see "Reading on the counter after one revolution of the red pointer", in the table).

Ballrace rotation: maximum reading accuracy.

Available readings														
0000,2 0000,5	0000,8	0001,0	0001,2	0001,2(5)	0001,4	0002,0	0002,5	0002,5(3)	0002,7(7)	0002,8(571)	0003,0	0003,5	0004,0	0005,0
Standard readings					Sp	Special readings on request (min. 10 pcs.)								

IP protection

The ultrasonic welding of the window to the case guarantees the complete sealing with IP 67 protection class, see <u>IEC 529</u> table.

Features and applications

Digital-analogue gravity position indicators are suitable with handwheels or knobs on spindles with horizontal or max 60° inclined axis.

To choose the handwheel see the table "Handwheels/knobs-possible assembly with indicators".

Special executions on request

- no pointer
- plain dial
- special dial with logo or customized graduations
- special readings after one revolution.

Instructions

These indicators are supplied with a screw on the rear case to prevent the mechanism from rotating during transportation, avoiding any displacement of reading. Before assembling the indicator into the handwheel, remove the screw from the back and fit the self-adhesive element supplied to guarantee IP 67 sealing.

	Standard	Elements	5		Deading accuracy of the	Deading on the counter	Weig
Clo	ockwise	Anti-o	clockwise	Dial graduation (No. divisions)	Reading accuracy of the red pointer on the graduated dial	Reading on the counter after one revolution of the red pointer	
Code	Description	Code	Description		graduated dial	the red pointer	g
CE.72241	GW12- 0000.2-D	CE.72242	GW12- 0000.2-S	20	0.01	0000.2	120
CE.72401	GW12- 0000.5-D	CE.72402	GW12- 0000.5-S	50	0.01	0000.5	120
CE.72501	GW12- 0001.0-D	CE.72502	GW12- 0001.0-S	100	0.01	0001.0	120
CE.72581	GW12- 0002.0-D	CE.72582	GW12- 0002.0-S	40	0.05	0002.0	120
CE.72621	GW12- 0002.5-D	CE.72622	GW12- 0002.5-S	50	0.05	0002.5	120
CE.72651	GW12- 0003.0-D	CE.72652	GW12- 0003.0-S	60	0.05	0003.0	120
CE.72701	GW12- 0004.0-D	CE.72702	GW12- 0004.0-S	80	0.05	0004.0	120

CE.72741	GW12- 0005.0-D	CE.72742	GW12- 0005.0-S	100	0.05	0005.0	120			
Other ratios avaible (min. quantity 10 pcs.)				Special executions on request						
000	1.2, 0001.2((5), 0001.4	, 0003.5	No pointer, plain dial - Special dial - Special readings after one revolutic						



ELESA and GANTER models all rights reserved in accordance with the law. Always mention the source when reproducing our drawings.

STANDARD MACHINE ELEMENTS WORLDWIDE